


Operating- and Installation Instructions BlueSky Manually Operated

Marine Roof



English

Table of Contents

1	About this document	3
1.		
1.2		
1.3	3 Use of symbols and highlighting	3
1.4	4 Warranty and liability	3
2	Safety	3
2.	-	
	2 Safety information	
	•	
3	Operation	4
4	Scope of Delivery	4
	•	
5	Required tools and materials	4
5 6		
	Installation	4
6	Installation 1 Requirements roof	4
6 .	Installation	4
6 6	Installation Requirements roof	4
6.6.6.6.6.6	Installation 1 Requirements roof	4
6.6.6.6.6.6.6	Installation 1 Requirements roof	4
6.3 6.3 6.4 6.5	Installation 1 Requirements roof. 2 Cut-out	4

1 About this document

1.1 Purpose of this document

The operating – and installation instructions are an integral part of the product and contain all the information required to ensure correct and safe operation and installation.

1.2 Using this document

Before operating or installing the unit, read these instructions.

1.3 Use of symbols and highlighting



CAUTION

This signal word denotes a hazard with a low degree of risk which, if not avoided, will lead to minor or moderate injury.



NOTE

This signal word denotes a Special Technical Feature or (if not observed) potential damage to the product.

Symbol Explanation

- Requirements for the following necessary action
- Necessary action

1.4 Warranty and liability

Webasto shall not assume liability for defects or damage that are the result of the installation and operating instructions being disregarded.

This liability exclusion particularly applies for:

- Installation by untrained personnel
- Improper use
- Repairs not carried out by a Webasto service workshop
- Use of non-genuine parts
- Conversion of the unit without permission from Webasto
- Mechanical damage to the equipment
- Failure to comply with inspection and maintenance instructions

2 Safety

2.1 Intended use

The BlueSky Manually Operated is a manually operated sliding roof for ventilation purposes. The BlueSky is designed for a large range of applications and can be installed easily in various motor boats.

It is suitable for fitting in area III and usage for motor boats with design-category B according to ISO 12216.

2.2 Safety information



CAUTION

Observe the following safety information:

Description



Take care not to hold any body parts, animals etc. through the roof opening when closing the roof!



Do not stand or walk on the roof!



Do not use the sliding roof as escape hatch! Make sure that another hatch is accessible for emergencies.



Close the roof when it starts to rain.

Table 1: Safety information

3 Operation

Use the handle bar to operate the BlueSky Manually Operated. See Fig. 1 - Fig. 3.




Fig. 1: Rotate the handle bar to the tilt position




Fig. 2: Slide the roof to the desired position




Fig. 3: Lock the roof in open position

4 Scope of Delivery

Description



Top frame (incl. mechanism and handle bar)



Panel assembly (including tool bit for fixing screws)



Rails, left and right, and rail end caps (2x)

Ope

Connection material (screws, washers, rings)

Operating – and Installation Instructions

Table 2: Scope of Delivery

5 Required tools and materials

Description
Standard tools
Hardware to fix the top frame and the rear rails: screws M5 stainless steel, pan dome or round head
High quality, acid free, UV resistant, sealant
Loctite 243

Table 3: Require tools and materials

6 Installation

6.1 Requirements roof

Sliding roof has to be installed on flat, un-curved surface. Deck / roof / surface must be sufficiently strong at installation point. If not, reinforcement must be made.

6.2 Cut-out




Fig. 4: BlueSky Installation opening

	W [mm]	L [mm]	R [mm]
Model	720	770	65
Model	500	500	65

Table 4: Dimensions cut-out

▶ Make a cut-out in the deck / roof according the table.

6.3 Top frame




Fig. 5: Frame drilling holes

- ▶ Place the top frame of the roof in the cut out.
- Fixate frame temporarily.
- ▶ Drill fixing holes. (Ø 4,2 mm).
- ▶ Remove top frame.
- If necessary (aluminum or steel deck): cut thread M5 in fixing holes.




Fig. 6: Apply a bead of sealant

▶ Apply a bead of sealant along the contour of the roof cutout.




Fig. 7: Top frame mounting

- ▶ Place the top frame again.
- ▶ Place and tighten fixing screws (4 Nm)

6.4 Panel




Fig. 8: Panel mounting

▶ Place panel assembly on top frame.



NOTE

Apply Loctite 243 on the threads

- Attach panel assembly to LH and RH mechanism with 2x2 bolts M5x16.
 Tightening torque: 4 Nm.
- ▶ Align panel assembly with the top frame. Maximum deviation left-right and front-rear: 2 mm.

6.5 Rear rails




Fig. 9: Rear rail positioning

- ▶ Slide rails through sliding mechanisms.
- ▶ Place rear rails against top frame.




Fig. 10: Rear rails drilling

With closed roof:

- ▶ Make sure that rear rails are parallel and perpendicular to rear beam of top frame.
- ► Measure distance between rear rails near sliding bracket.
- ▶ Drill fixing holes Ø 4,2 mm and cut thread M5 in deck / roof / surface (LH and RH).




Fig. 11: Criteria for screw

▶ Place fixing screws in holes, just hand-tight. Use pan, dome or round head screws, fulfilling the criteria above. I.e. ISO7380.

Alternative fixation with self-tapping screws:

- ▶ Drill holes with correct diameter.
- ▶ Place screws in holes.




Fig. 12: Rear rails drilling, rear holes

▶ Open sliding roof completely.

If necessary, close the roof a bit, until last hole in each rail can be accessed.

- Check if distance between rear rails is same as measured before
- ▶ Drill rear fixing holes Ø 4,2 mm and cut thread M5 in deck / roof / surface.
- ▶ Place fixing screw in each hole, just hand-tight.

Alternative fixation with self-tapping screws:

▶ Drill holes with correct diameter.

- ▶ Place screws in the holes.
- ► Close sliding roof again, drill remaining fixing holes Ø 4,2 mm and cut thread M5 in deck / roof / surface.

Alternative fixation with self-tapping screws:

- ▶ Drill holes with correct diameter.
- ► Remove the rear rails.



Fig. 13: Rear rails sealing

► Apply bead of sealant around all fixing holes.




Fig. 14: Rear rails fitting

- ▶ Place rear rails and all fixing screws.
- ► Tighten fixing screws (4 Nm).
- ▶ Place and fix the rear rail end caps.

7 Maintenance

\i\

CAUTION

Cleaning agents can contain harmful components

Damage to the product

► Never use solvents.

Clean the sliding roof regularly:

- ▶ Wash the roof with lukewarm water.
- ▶ Then rinse the roof with clean water.

8 Technical data

For detailed technical data, see https://dealers.webasto.com.

9 CE declaration




Fig. 15: BlueSky - CE declaration

These are the original instructions. The English language is binding.

You can request your language if it is missing. The telephone number of each country can be found in the Webasto service centre leaflet or the website of the respective Webasto representative of your country.

Webasto Thermo & Comfort SE Postfach 1410 82199 Gilching Germany

Company address: Friedrichshafener Str. 9 82205 Gilching Germany



www.webasto.com